




SPARE PARTS LIST

DRILLING EQUIPMENT


DS 500, 2019-04

A DS 500 ANCHOR BASE




| Ref | Part No | Description | Remark | QTY KIT | |
|-----|--------------|---------------------|--------|---------|----|
| 1 | 597 60 93-01 | BASEPLATE | | 1 | |
| 2 | 597 59 18-01 | SCREW KIT | | 1 | 1 |
| 3 | 725 25 42-51 | SCREW EHHM | | | |
| 4 | 586 62 56-01 | BOSS | | | |
| 5 | 597 59 14-01 | HINGE PLATE | | 1 | 1 |
| 6 | 732 25 22-01 | HEXAGON LOCKING NUT | | | 5 |
| 7 | 734 11 78-01 | WASHER | | | 5 |
| 8 | 595 83 84-01 | HINGE PLATE | | | 5 |
| 9 | 725 25 58-51 | SCREW EHHM | | | 5 |
| 10 | 597 60 97-01 | SCREW KIT | | 1 | 1 |
| 11 | 597 60 98-01 | GUARD | | 1 | 1 |
| 12 | 541 40 48-92 | GUARD | | | 12 |
| 13 | 597 60 94-01 | HINGE PLATE | | 1 | 1 |

B DS 500
BACK SUPPORT



| Ref | Part No | Description | Remark | QTY | KIT |
|-----|--------------|---------------|--------|-----|-----|
| 1 | 597 61 15-01 | BAR | | 1 | |
| 2 | 597 61 12-01 | LOCKING SHAFT | | 1 | 1 |
| 3 | 597 61 11-01 | HOLDER KIT | | 1 | 1 |
| 4 | 596 21 72-01 | BAR | | | |
| 5 | 586 62 56-01 | BOSS | | | |
| 6 | 734 11 78-01 | WASHER | | | |




CARRIAGE

DS 500, 2019-04

| Ref | Part No | Description | Remark | QTY KIT |
|-----|--------------|------------------|--------|---------|
| 1 | 597 62 16-01 | CARRIAGE | | |
| 2 | 597 61 45-01 | GEAR WHEEL KIT | | 1 |
| 3 | 597 61 47-01 | BRACKET | | |
| 4 | 582 08 81-01 | BEARING | | 3 |
| 5 | 597 61 48-01 | GEAR WHEEL SHAFT | | |
| 6 | 597 61 50-01 | GEAR WHEEL KIT | | |
| 7 | 597 61 52-01 | WHEEL KIT | | |
| 8 | 597 61 53-01 | WHEEL KIT | | |
| 9 | 582 08 72-01 | SHAFT | | |
| 10 | 582 08 70-01 | SHAFT | | |
| 11 | 597 61 54-01 | GEAR WHEEL SHAFT | | |
| 12 | 541 40 50-36 | LEVEL | | |
| 13 | 504 90 83-09 | CASE | | |
| 14 | 720 18 28-51 | PARALLEL PIN | | |
| 15 | 734 11 86-01 | WASHER | | |
| 16 | 597 61 56-01 | LOCKING PLATE | | |
| 17 | 597 61 57-01 | COVER KIT | | |
| 18 | 593 57 06-01 | SCREW | | |
| 19 | 734 11 63-01 | WASHER | | |
| 20 | 597 61 58-01 | BRAKE | | |
| 21 | 541 40 50-39 | HANDLE | | |
| 22 | 531 14 06-72 | GRIP | | |

D DS 500
COLUMN



| Ref | Part No | Description | Remark | QTY | KIT |
|-----|--------------|--------------|--------|-----|-----|
| 1 | 597 61 32-01 | COVER KIT | | 1 | |
| 2 | 597 61 33-01 | COLUMN ASSY | | 1 | |
| 3 | 593 06 76-01 | GEAR RACK | | 1 | 2 |
| 4 | 504 46 00-02 | SCREW | | 24 | 2 |
| 5 | 596 92 14-01 | CONSOLE ASSY | | 1 | 2 |
| 6 | 579 79 94-01 | RAIL | | 2 | 2 |
| 7 | 503 20 00-46 | SCREW EHHFM | | 6 | 2 |